


Manual Roam on a Symbian Series 60 (E-series) Nokia


To perform a manual roam press your **Menu** key and select **Tools**.



Select **Settings** and then **Phone**.



Go to **Network** and change the **Operator Selection** to **Manual**.



Select another Network from the list that appears. This will give you the message **No access!** Once you have done this select your Home network to complete the manual roam.

