

Manual Network Roam (on an OS 7 device)

Navigate to the **Options** menu



Choose **Networks and Connections**



Choose **Mobile Network**



Network Selection mode choose **Manual**



The handset will scan for available networks



You can now choose the desired network from the list shown.

